

## Vette Net C5 Installation

The Vette Net is shipped with two brackets, one for the right side and one for left. The Vette Net is configured to go up and over your center waterfall. Vette Net will require approx 1 inch of space behind your seat.



Open the hatch cover, set each bracket over the hinge on each side of the car located behind the seat belt. Legs should be pointed downward toward the carpet so that the hatch will close. A strong push on the hatch will lock the brackets and the hatch in place.



Insert the Vette Net legs into each pipe and gently tap on the top of the net to make sure it sets all the way down into the legs.  
Close the hard boot.



That's it! You are ready to enjoy a topless ride in comfort and pleasure. We recommend that you store your Net and brackets in one of our storage bags away from extreme heat and cold when not in use.