

**Carbon Fiber Side Mirror Replacement:
Chevrolet Corvette C6 2005-Up
#CBM-VETTC6**

Installation Manual



Thank you for purchasing the Carbign Craft Carbon Fiber Side Mirror Replacement. Please follow the following steps on how to install this product to your vehicle.



Remove the door panel.

Remove the speaker.

Unplug connectors for the power and heated mirror.



Find and unplug the yellow XM Radio connector (2006-Up with XM option)



Feed wire through rubber tunnel.



Remove the mirror assembly from the vehicle. The gasket will be re-used.



Carefully pry off the mirror lens.



Unplug wires from mirror lens.



Remove two small Torx screws. The new housing will have two new screws to replace these.



Find the one-time use round clip under the mirror base.

This round clip holds the swivel mechanism together.



Drill out and remove the round clip.

Once the round clip is removed, the swivel mechanism will come apart and can no longer be re-assembled.



Discard the round clip.



Remove two screws at the bottom of the main housing. One of these screws will be re-used in the new housing.

Remove the internal parts (motor, brackets, wires, etc.).



Transfer internal parts to the new housing.

Use the supplied hardware to secure the internal parts. Re-use one screw that was saved from the previous step.

Attach new mirror assembly to the vehicle and plug in all connections, and repeat for the other mirror.