

C5 WINDOW SWITCH LEDS



Remove the drivers window switch by prying up on the **BOTTOM** of the switch. Use a flat blade screwdriver and a shop towel to protect the panel and switch. Press the release tab and unplug the switch.



There are 4 sockets that need to be removed. Using a flat blade screwdriver that fits the slot exactly, twist 1/4 turn counterclockwise and remove.



Insert the new led modules into the switch panel by aligning the locking tabs (green arrow), with the slots in the panel (red arrow). Using your finger, push the leds into the panel until they seat.



Once the led is fully seated, Twist the socket clockwise 1/4 turn using some downward pressure to lock it into place.



Leds are polarity sensitive so you need to plug the panel in to test the leds. If any of them don't light you need to remove and turn them 180 degrees and re-install them. To remove, twist them 1/4 turn counterclockwise. A pair of hemostats with teeth on the jaws or a small pair of needle nose pliers works well for removing the sockets. There are 2 small holes at the end of the screwdriver slot you can use to lift the socket out. **DO NOT** try and turn them into position with anything but a proper screwdriver. The interior lights will "time out" after about 15 minutes so you may have to re-activate them.



Now remove the passenger side panel by prying up on the **TOP** of the panel. Remove and unplug the panel and using the same procedure as before, install the 2 leds. Again, they are polarity sensitive so you may need to turn them 180 degrees if they don't light. Always keep in mind that the interior light may "time out" after about 15 minutes so you may need to re-activate the interior lights. Re install both panels and enjoy the new lights!